

How to Order

Air Output Port: KBV, KBZ (P. 15-2-113)



Branch Elbow Module: KBZ

Model	Applicable tubing O.D.
KBZ1-04	4
KBZ1-06	6
KBZ2-08	8
KBZ3-10	10
KBZ3-12	12
KBZ4-12	12



Wiodei	O.D.
KBV1-04	4
KBV1-06	6
KBV2-06	
KBV2-08	8
KBV3-08	
KBV3-10	10
KBV3-12	12
KBV4-12	
KBV4-16	16

Elbow Module: KBV


Juei	O.D.	
/1-04	4	
/1-06	,	
/2-06	6	
/2-08	0	
/3-08	8	Applicati
/3-10	10	Applicable tubing
/3-12	12	
/4-12	12	

Elbow Socket Module: KBV

Model	T Connection thread	01
KBV1-M5	M5 x 0.8	
KBV1-M6	M6 x 1	
KBV2-M5	M5 x 0.8	
KBV2-M6	M6 x 1	 (<u> </u> <u> </u>
KBV2-R1	Bc 1/8	
KBV3-R1	110 /6	
KBV3-R2	Rc 1/4	0 0
KBV4-R2	110 74	
KBV4-R3	Rc 3/8	




Air Supply Port: KBE, KBH, KBB, KBS, KBL (P. 15-3-114, 115)



Model KBE1-04

KBE1-06 KBE2-06 KBE2-08 **KBE2-10** KBE3-08 **KBE3-10** 10 KBE3-12 12 **KBE4-12**



Bulkhead Female Connector: KBE Female Connector Union: KBH

Model	T Connection thread
KBH1-R1S	R 1/8
KBH2-R1S	
KBH2-R2S	R 1/4
KBH2-R3S	R3/8
KBH3-R2S	R 1/4
KBH3-R3S	R3/8
KBH3-R4S	R 1/2
KBH4-R3S	R3/8
KBH4-R4S	R 1/2



With sealant (Male thread only).... · · Standard specifications

Tube size/Connection thread size

Male Connector Socket: KBB

T Connection thread
M5 x 0.8
M6 x 1
Rc 1/8
Rc1/4

Body size


Female Connector Socket: KBS


Model	T Connection thread
KBS1-R1	Rc 1/8
KBS2-R2	Rc 1/4
KBS3-R3	Rc 3/8
KBS4-R4	Rc 1/2




Female Connector Elbow Union: KBL

Model	T Connection thread
KBL1-R1S	R ¹ /8
KBL2-R1S	
KBL2-R2S	R1/4
KBL2-R3S	R3/8
KBL3-R2S	R1/4
KBL3-R3S	R3/8
KBL3-R4S	R1/2
KBL4-R3S	R3/8
KBL4-R4S	R1/2










Model
KBP1
KBP2
KBP3
KBP4




Model

Cap: KBC

Model	5
KBC1	
KBC2	<u> </u>
KBC3	Bracket L
KBC4	mounting /
	thread M6 x 1 x 8 t






Bracket: KBX

Model	
KBX6	
KBX12	
KBX14	
KBX16	
KBX20	
KBX22	





Combination Examples



 $\mathsf{K}\square$

 $\mathsf{M}\square$

 $H\square$

 $\mathsf{D}\Box$

MS

T□

VMG