



## Construction

### Double acting



Without magnet

### Single acting, spring return



Without magnet

\* The numbers are the same as the "Construction" of the Best Pneumatics No.2 Series CUJ.

### Seal Kit List

No.	Description	Material	Note
⑪	Piston seal	NBR	
⑫	Rod seal		
⑬	Tube gasket		

### Replacement Parts: Seal Kit

Bore size (mm)	Kit no.	Contents
<b>Double acting</b>		
4	<a href="#">CUJB4-PS</a>	Set of left nos. ⑪, ⑫, ⑬ and grease pack.
6	<a href="#">CUJB6-PS</a>	
8	<a href="#">CUJB8-PS</a>	
10	<a href="#">CUJB10-PS</a>	


\* Seal kit ⑪ to ⑬ comes as a set. Use the kit number for each bore size.

### Single acting, spring return


Bore size (mm)	Kit no.	Contents
4	<a href="#">CUJB4-S-PS</a>	Set of left nos. ⑪ and grease pack.
6	<a href="#">CUJB6-S-PS</a>	
8	<a href="#">CUJB8-S-PS</a>	
10	<a href="#">CUJB10-S-PS</a>	

\* Use the following part number for ordering a grease pack only.

Grease pack part no.: GR-L-005 (5 g)

**Construction****Double acting**

Without magnet

**Single acting, spring return**

Without magnet

\* The numbers are the same as the "Construction" of the Best Pneumatics No.2 Series CUJ.

**Seal Kit List**

No.	Description	Material	Note
⑬	Piston seal	NBR	
⑭	Rod seal		
⑮	O-ring		

**Replacement Parts: Seal Kit**

Bore size (mm)	Kit no.	Contents
<b>Double acting</b>		
12	<a href="#">CUJB12-PS</a>	Set of left nos. ⑬, ⑭, ⑮ and grease pack.
16	<a href="#">CUJB16-PS</a>	
20	<a href="#">CUJB20-PS</a>	

\* Seal kit ⑬ to ⑮ comes as a set. Use the kit number for each bore size.

**Single acting, spring return**

12	<a href="#">CUJB12-S-PS</a>	Set of left nos. ⑬ and grease pack.
16	<a href="#">CUJB16-S-PS</a>	
20	<a href="#">CUJB20-S-PS</a>	

\* Use the following part number for ordering a grease pack only.

**Grease pack part no.:** GR-L-005 (5 g)