


# Space Saving Vacuum Ejector/Vacuum Pump System

## Series ZQ



Width 10 mm  
Weight 109 g  
Single unit with vacuum pressure switch and suction filter



**Ejector**  
P.1



**Pump System**  
P.15


**NEW**

### Easy-to-use vacuum pressure switch

- Push button type provides easy operation.




- Vacuum pressure switch with LED display
- With One-touch fittings
- NPN open collector 1 output + analog voltage
- PNP open collector 1 output + analog voltage
- NPN open collector 2 outputs
- PNP open collector 2 outputs



### Can copy to up to 10 switches simultaneously.

The settings of the master pressure switch (source of copy) can be copied to the slave pressure switches.


- Reduction in setting work
- Prevention of mistakes in setting



# Space Saving Vacuum Ejector Series ZQ




[Option]  
Note) CE-compliant:  
For DC only.



## How to Order

### Ejector Unit

**Made to Order** For "Made to Order", refer to page 13.



#### ① Nozzle nominal size

05	ø0.5
07	ø0.7
10	ø1.0

#### ② Exhaust type

1U	With silencer for single unit
3M	With silencer for manifold

#### ③ Solenoid valve combination (Refer to Table (1).)

Symbol	Supply valve	Vacuum release valve
<b>K1</b>	Normally closed	Normally closed
<b>K2</b> <small>Note 1)</small>	Normally open	Normally closed
<b>J1</b>	Normally closed	None
<b>J2</b> <small>Note 1)</small>	Normally open	None
<b>Q1</b>	Latching positive common	Normally closed
<b>Q2</b>	Latching positive common	None
<b>N1</b>	Latching negative common	Normally closed
<b>N2</b>	Latching negative common	None

Note 1) In cases when K2 or J2 (supply valve normally open) is selected for the solenoid valve combination, when vacuum is stopped for long periods of time (10 minutes or more), do not continue to energize the supply valve, and shut off the air supply.

#### ④ Pilot valve (Refer to Table (1).)

<b>Nil</b>	Standard (DC: 1 W) <small>Note 2)</small>
<b>Y</b>	DC low wattage type (0.5 W) <small>Note 2)</small>

Note 2) Avoid energizing the solenoid valve for long periods of time. (Refer to Design and Selection on Specific Product Precautions.)

#### ⑤ Solenoid valve rated voltage (Refer to Table (1).)

		CE compliant
<b>1</b> <small>Note 3)</small>	100 VAC (50/60 Hz)	—
<b>2</b> <small>Note 3)</small>	200 VAC (50/60 Hz)	—
<b>3</b> <small>Note 3)</small>	110 VAC (50/60 Hz)	—
<b>4</b> <small>Note 3)</small>	220 VAC (50/60 Hz)	—
<b>5</b>	24 VDC	●
<b>6</b>	12 VDC	●




Note 3) CE compliant products are not available for "1", "2", "3" and "4".

**Table (1) Combination of Solenoid Valve, Pilot Valve and Power Supply Voltage**

Combination no.	Solenoid valve combination symbol	Pilot valve symbol	Applicable power supply voltage (V)					
			100 AC	200 AC	110 AC	220 AC	24 DC	12 DC
①	<b>K1</b>	<b>Nil</b>	—	—	—	—	●	●
②	<b>K1</b>	<b>Y</b>	—	—	—	—	●	●
③	<b>K2</b>	<b>Nil</b>	—	—	—	—	●	●
④	<b>J1</b>	<b>Nil</b>	●	●	●	●	●	●
⑤	<b>J1</b>	<b>Y</b>	—	—	—	—	●	●
⑥	<b>J2</b>	<b>Nil</b>	—	—	—	—	●	●
⑦	<b>Q1</b>	<b>Nil</b>	—	—	—	—	●	●
⑧	<b>Q2</b>	<b>Nil</b>	●	●	●	●	●	●
⑨	<b>N1</b>	<b>Nil</b>	—	—	—	—	●	●
⑩	<b>N2</b>	<b>Nil</b>	—	—	—	—	●	●

\* Combinations ① to ⑩ in the above table are the only possible options.

## ⑥ Electrical entry

<b>L</b>	L-type plug connector, with 0.3 m lead wire, with light/surge voltage suppressor	
<b>LO</b>	L-type plug connector, without connector, with light/surge voltage suppressor	
<b>G</b>	Grommet, with 0.3 m lead wire (Latching/AC type: Not applicable)	

## ⑦ Manual override Note 4)

<b>Nil</b>	Non-locking push type Latching type: Push-locking type
<b>B</b>	Locking type (Q1/Q2/N1/N2: Not applicable)

Note 4) Latching type supply valve: Available in "Nil" only.  
In this case, the supply valve and release valve come with a push-locking type.

## ⑧ Vacuum pressure switch suction filter Note 5)

<b>EA</b>	0 to -101 kPa/NPN open collector 2 outputs, with suction filter
<b>EB</b>	0 to -101 kPa/PNP open collector 2 outputs, with suction filter
<b>EC</b>	0 to -101 kPa/NPN open collector 1 output + analog voltage, with suction filter
<b>EE</b>	0 to -101 kPa/PNP open collector 1 output + analog voltage, with suction filter
<b>FA</b>	100 to -100 kPa/NPN open collector 2 outputs, with suction filter
<b>FB</b>	100 to -100 kPa/PNP open collector 2 outputs, with suction filter
<b>FC</b>	100 to -100 kPa/NPN open collector 1 output + analog voltage, with suction filter
<b>FE</b>	100 to -100 kPa/PNP open collector 1 output + analog voltage, with suction filter
<b>F</b>	Suction filter only

Note 5) The filter included in this product is of a simple type, and will become clogged quickly in environments with high quantities of dust or particulates. Please make additional use of an air suction filter of the ZFA, ZFB or ZFC series.

### **Warning**

The filter case of this suction filter is made of nylon. Contact with alcohol or similar chemicals may cause it to be damaged. Also, do not use the filter when these chemicals are present in the atmosphere.

## ⑪ Check valve Note 8)

<b>Nil</b>	None
<b>K</b>	With check valve

Note 8) The check valve has a function to prevent the exhaust air from the silencer overflowing to the vacuum port side when a manifold is used. However, depending on usage conditions, it does not always suppress air overflow to the desired extent. During usage, please inspect thoroughly with actual machine.  
Also, in order to completely prevent the overflow of exhaust air, leave plenty of space between the check valve unit and adjacent ejector to avoid interference from the ejector's exhaust unit.

### **Warning**

- Cannot be used for vacuum retention.
- Use a release valve. (Without a release valve, a workpiece may not be released.)

## ⑫ Fitting (V port) Note 9)

Symbol	Applicable tubing O.D.	Part no.	
		Vacuum pressure switch	Filter only
<b>0</b>	Without fitting (M5 x 0.8)	VVQ1000-50A-M5	—
<b>1</b>	ø3.2 (Straight)	VVQ1000-50A-C3	KJS23-M5
<b>2</b>	ø4 (Straight)	VVQ1000-50A-C4	KJS04-M5
<b>3</b>	ø6 (Straight)	VVQ1000-50A-C6	KJS06-M5
<b>4</b>	ø3.2 (Elbow)	VVQ1000-F1-LC3	KJL23-M5
<b>5</b>	ø4 (Elbow)	VVQ1000-F1-LC4	KJL04-M5

## ⑬ Fitting (P port) Note 9)

Symbol	Applicable tubing O.D.	Part no.	Object spec.
<b>Nil</b>	Without port	—	Manifold
<b>0</b>	Without fitting (M5 x 0.8)	—	Single unit
<b>2</b>	ø4 (Straight)	KJS04-M5	
<b>3</b>	ø6 (Straight)	KJS06-M5	
<b>5</b>	ø4 (Elbow)	KJL04-M5	

## ⑭ Bracket A

<b>Nil</b>	With bracket A
<b>N</b>	Without bracket A

## ⑮ CE-compliant

<b>Nil</b>	—
<b>Q</b>	CE-compliant

Note) CE-compliant: For DC only.

Note 9) For filter only (Without vacuum pressure switch)

When neither V port fitting nor P port fitting are needed, enter nothing or -00 in the dotted line above "How to Order".

## How to Order

### Manifold ZZQ1 07 - B S C

Number of stations Note)

01	1 station
02	2 stations
⋮	⋮
08	8 stations

Note) Number of stations varies according to nozzle nominal size during simultaneous operation.

Maximum Number of Stations in Simultaneous Operation

Nozzle nominal size	Maximum number of stations in simultaneous operation
∅0.5	8 stations
∅0.7	6 stations
∅1.0	4 stations

Air pressure supply (P) port position

**B** Both sides


Exhaust

**S** With silencers (Both sides)

Vacuum release pressure supply port (PD port)

**B** None (Release pressure is supplied from the P port.)


**C** Provided (Air can be alternatively supplied from the P port.)



## Manifold Ordering Example


- ZZQ108-BSB → 1 pc.
- \*ZQ1053M-K1Y5L-EAG (-Q) → 4 pcs. (Stations 1 to 4)
- \*ZQ1103M-K1Y5L-EAG (-Q) → 4 pcs. (Stations 5 to 8)

Note) By viewing the front side of vacuum port (V), stations are counted starting from station 1 on the left side.




## Flow/Exhaust Characteristics


### ZQ105 / Exhaust Characteristics




### ZQ105 / Flow Characteristics




### ZQ107 / Exhaust Characteristics




### ZQ107 / Flow Characteristics




### ZQ110 / Exhaust Characteristics



### ZQ110 / Flow Characteristics



## How to Read Flow Characteristics



Flow characteristics are expressed in ejector vacuum pressure and suction flow. If suction flow rate changes, a change in vacuum pressure will also be expressed. Normally this relationship is expressed in ejector standard use.

In the graph, **Pmax** is max. vacuum pressure and **Qmax** is max. suction flow. The valves are specified according to catalog use. Changes in vacuum pressure are expressed in the below order.

1. When ejector suction port is covered and made airtight, suction flow becomes 0 and vacuum pressure is at maximum value (**Pmax**).
2. When suction port is opened gradually, air can flow through, (air leakage), suction flow increases, but vacuum pressure decreases. (condition **P1** and **Q1**)
3. When suction port is opened further, suction flow moves to maximum value (**Qmax**), but vacuum pressure is near 0. (atmospheric pressure).

When vacuum port (vacuum piping) has no leakage, vacuum pressure becomes maximum, and vacuum pressure decreases as leakage increases. When leakage value is the same as max. suction flow, vacuum pressure is near 0.

When ventirative or leaky work must be adsorbed, please note that vacuum pressure will not be high.

## ⚠ Precautions

Be sure to read before handling. Refer to "Handling Precautions for SMC Products" (M-E03-3) for Safety Instructions and Vacuum Equipment Precautions.

## ⚠ Caution

Refer to the vacuum equipment model selection on Best Pneumatics No.④ for the selecting and sizing of Series ZQ.

## Specifications

### Ejector

Model	ZQ105	ZQ107	ZQ110
Nozzle nominal diameter (mm)	0.5	0.7	1.0
Maximum suction flow (l/min (ANR))	5	10	22
Air consumption (l/min (ANR))	14	23	46
Maximum vacuum pressure	-80 kPa		
Supply pressure range	0.3 to 0.5 MPa (Normally open: 0.3 to 0.45 MPa)		
Supply pressure <sup>(Note)</sup>	0.35 MPa	0.43 MPa	
Operating temperature range	5 to 50°C		
Fluid	Air / Inert gas		

Note) Maximum suction flow can be obtained by standard supply pressure.

### Weight

Single unit	With suction filter <sup>Note 1)</sup>	95 g
	With vacuum pressure switch and suction filter <sup>Note 2)</sup>	109 g
End plate assembly for manifold		122 g

Note 1) Including a 0.3 m connector for supply valve and vacuum release valve.

Note 2) Including a 0.3 m connector for supply valve and vacuum release valve and a 2 m connector for vacuum pressure switch.

◎ Calculation of weight for the manifold type  
(Single unit weight) x (Number of stations) + (Weight of end plate assembly for manifold)

Example) Vacuum pressure switch + 8 stations with suction filter  
109 g x 8 + 122 g = 994 g

### Supply Valve / Vacuum Release Valve

Type	Normally closed		Latching type	Normally open
	Standard (1 W)	Low wattage type (0.5 W)		
Model (Refer to "How to Order" for solenoid valves on page 6.)	VQ110-□	VQ110Y-□	VQ110 <sub>N</sub> -□	ZQ1-VQ120-□
Manual override	Non-locking push type / Locking type (Tool type)		Push-locking type	Non-locking push type / Locking type (Tool type)
Rated coil voltage	12, 24 VDC, 100, 110, 200, 220 VAC	12, 24 VDC	12, 24 VDC, 100, 110, 200, 220 VAC	12, 24 VDC
Power consumption (current value)	DC	1 W	1 W	
	100 VAC	0.5 VA (5 mA)	—	0.6 VA (6 mA)
	110 VAC	0.55 VA (5 mA)	—	0.65 VA (5.9 mA)
	200 VAC	1.0 VA (5 mA)	—	1.2 VA (6 mA)
	220 VAC	1.1 VA (5 mA)	—	1.3 VA (5.9 mA)
Electrical entry	Grommet		L-type plug connector	Grommet
	L-type plug connector (with light/surge voltage suppressor)		( with light/surge voltage suppressor )	L-type plug connector ( with light/surge voltage suppressor )

# Series ZQ

## Specifications


### Vacuum Pressure Switch

Model	ZQ1-ZSE (ZSE10)	ZQ1-ZSF (ZSE10F)
Rated pressure range	0 to -101 kPa	-100 to 100 kPa
Set pressure range/Display pressure range	10 to -105 kPa	-105 to 105 kPa
Withstand pressure	500 kPa	
Minimum setting unit	0.1 kPa	
Power supply voltage	12 to 24 VDC $\pm 10\%$ , Ripple (p-p) 10% or less (with power supply polarity protection)	
Current consumption	40 mA or less	
Switch output	NPN or PNP open collector: 2 outputs (selectable)	
Maximum load current	80 mA	
Maximum applied voltage	28 V (with NPN output)	
Residual voltage	2 V or less (with load current of 80 mA)	
Response time	2.5 ms or less (Response time selections with anti-chattering function: 20, 100, 500, 1000 and 2000 ms)	
Short circuit protection	With short-circuit protection	
Repeatability	$\pm 0.2\%$ F.S. $\pm 1$ digit	
Hysteresis	Variable (0 or above) <sup>Note 1)</sup>	
Hysteresis mode		
Window comparator mode		
Analog output	Output voltage (rated pressure range)	1 to 5 V $\pm 2.5\%$ F.S.
	Linearity	$\pm 1\%$ F.S. or less
	Output impedance	Approx. 1 k $\Omega$
Display system	3 1/2-digit, 7 segment LED 1-color display (Red)	
Display accuracy	$\pm 2\%$ F.S. $\pm 1$ digit (at ambient temperature of 25 $\pm 3^\circ\text{C}$ )	
Operation indicator light	Lights when ON, OUT1: Green, OUT2: Red	
Environmental resistance	Enclosure	IP40
	Ambient humidity range	Operating/Stored: 35 to 85% RH (with no condensation)
	Withstand voltage	1000 VAC for 1 min. between live parts and case
	Insulation resistance	50 M $\Omega$ or more (at 500 VDC) between live parts and case
	Vibration resistance	10 to 150 Hz at the smaller of amplitude 1.5 mm or acceleration 20 m/s <sup>2</sup> in X, Y, Z directions for 2 hrs. each (De-energized)
Impact resistance	100 m/s <sup>2</sup> in X, Y, Z directions 3 times each (De-energized)	
Temperature characteristics	$\pm 2\%$ F.S. (at 25 $^\circ\text{C}$ of ambient temperature range between -5 and 50 $^\circ\text{C}$ )	
Lead wires	Oil-resistant cabtire cord Cross section: 0.15 mm <sup>2</sup> (AWG26), 5 cores, 2 m, Conductor O.D.: 1.0 mm	


Note 1) If the applied voltage fluctuates around the set-value, the hysteresis must be set to a value more than the fluctuating width, otherwise chattering will occur.  
Note 2) For others, refer to ejector specifications on page 4.

## Construction

### Single unit



### Manifold



### Component Parts

No.	Description	Material
1	Poppet valve assembly	—
2	Nozzle	Aluminum alloy
3	Diffuser	Aluminum alloy
4	Vacuum release flow adjustment needle	Aluminum alloy

### Replacement Parts

No.	Description	Material	Part no.
5	Solenoid valve	—	Refer to page 6.
6	Filter element	PVF	XT534-5-001-AS
7	Sound absorbing material 1 (single unit)	PVF	ZQ-SAE
8	Vacuum pressure switch	—	Refer to page 6
9	Sound absorbing material 2 (manifold)	PVF	ZZQ-SAE

**How to Order**

**Solenoid Valve**

**Actuation**

1 Normally closed

**VQ1 1 0** - **5 L**

**ZQ1-VQ1 2 0** - **5 L**

**Actuation**

2 Normally open

**Pilot valve**

Nil Standard (1 W)

**Solenoid valve rated voltage**

5	24 VDC
6	12 VDC

**Pilot valve**

Nil	Standard (DC: 1 W)
Y	Low wattage type (0.5 W) * AC type: Not applicable
L	Latching positive common
N	Latching negative common

**Connector assembly part no.**

1	100 VAC (50/60 Hz)
2	200 VAC (50/60 Hz)
3	110 VAC (50/60 Hz)
4	220 VAC (50/60 Hz)
5	24 VDC
6	12 VDC

**Solenoid valve rated voltage**

1	100 VAC (50/60 Hz)
2	200 VAC (50/60 Hz)
3	110 VAC (50/60 Hz)
4	220 VAC (50/60 Hz)
5	24 VDC
6	12 VDC

**Manual override** Note)

Nil	Non-latching push type
	Latching type: Push-locking type
B	Locking type

Note) Latching type: Available in "Nil" only

**Electrical entry** Note)

L	L-type plug connector, with 0.3 m lead wire	
LO	L-type plug connector, without connector	
G	Grommet, with 0.3 m lead wire (Latching/AC type: Not applicable)	

Note) Mounting screws are attached.

**How to order connector assembly**

- Single AXT661-14A-□
- DC positive common
- Latching AXT661-13A-□
- DC negative common
- Latching AXT661-13AN-□
- 100 VAC
- Single AXT661-31A-□
- Latching AXT661-32A-□
- 200 VAC
- Single AXT661-34A-□
- Latching AXT661-35A-□

**Lead wire length**

Nil	300 mm
6	600 mm
10	1000 mm
20	2000 mm
30	3000 mm

Connector, socket (3 pcs) only  
AXT661-12A

**Lead wire length of the plug connector**

The lead wire length for a valve with a lead wire is 300 mm. When in need of a valve with a lead wire longer than 600 mm, place an order for a valve without a connector and connector assembly.

**Vacuum Pressure Switch**

**ZQ1-ZS** - **A**

**Vacuum pressure switch specifications**

EA	0 to -101 kPa/NPN open collector 2 outputs, with suction filter
EB	0 to -101 kPa/PNP open collector 2 outputs, with suction filter
EC	0 to -101 kPa/NPN open collector 1 output + analog voltage, with suction filter
EE	0 to -101 kPa/PNP open collector 1 output + analog voltage, with suction filter
FA	100 to -100 kPa/NPN open collector 2 outputs, with suction filter
FB	100 to -100 kPa/PNP open collector 2 outputs, with suction filter
FC	100 to -100 kPa/NPN open collector 1 output + analog voltage, with suction filter
FE	100 to -100 kPa/PNP open collector 1 output + analog voltage, with suction filter

**Vacuum pressure switch unit specifications**

Nil	With unit switching function <small>Note 1)</small>
M	Fixed SI unit <small>Note 2)</small>
P	With unit switching function <small>Note 1)</small> (Initial value psi)

Note 1) Under the New Measurement Law, sales of switches with the unit switching function are not allowed for use in Japan.  
Note 2) Fixed unit: kPa

**Vacuum pressure switch lead wire specifications**

Nil	Without connector
G	Lead wire with connector (lead wire length 2 m) With connector cover

**Check valve** Note 3)

Nil	None
K	With check valve

Note 3) The check valve has a function to prevent the exhaust air from the silencer overflowing to the vacuum port side when a manifold is used, but it is incapable of completely preventing overflow. During usage, please inspect thoroughly with actual machine.  
Also, in order to completely prevent the overflow of exhaust air, leave plenty of space between the check valve unit and adjacent ejector to avoid interference from the ejector's exhaust unit.

**Warning**

- Cannot be used for vacuum retention.
- Use a vacuum release valve. (Without a vacuum release valve, the workpiece may not be released.)

**Fitting (V port)**

Symbol	Applicable tubing O.D.
0	Without fitting (M5 x 0.8)
1	ø3.2 (Straight)
2	ø4 (Straight)
3	ø6 (Straight)
4	ø3.2 (Elbow)
5	ø4 (Elbow)

Lead wire with connector part no.	Note
ZS-39-5G	Lead wire length 2 m (With connector cover)

\* The vacuum pressure switch mounted on this product is equivalent to our SMC product, the ZSE10 series compact digital pressure switch.

**Pressure switch correspondence table**

Vacuum Ejector Series ZQ	ZQ1□□-□□□□□-□□□□□-□□□□□
Vacuum Pressure Switch for ZQ	ZQ1-ZS□□□□□-□□-□□□□□
Digital Pressure Switch Series ZSE10	ZSE10□□□□□-□□□□□

**Rated pressure range/Output specifications**  
(Refer to rated pressure range/output specifications correspondence table)

- Vacuum pressure switch lead wire specification
- Vacuum pressure switch unit specification

**Rated pressure range/Output specifications correspondence table**

Vacuum pressure switch for ZQ	Series ZSE10	Specification
ZQ1-ZSEA□□□□□-□□-□□□□□	ZSE10-□□-□□□□□	0 to -101 kPa/NPN open collector 2 outputs
ZQ1-ZSEB□□□□□-□□-□□□□□	ZSE10-□□-□□□□□	0 to -101 kPa/PNP open collector 2 outputs
ZQ1-ZSEC□□□□□-□□-□□□□□	ZSE10-□□-□□□□□	0 to -101 kPa/NPN open collector 1 output + analog voltage
ZQ1-ZSEE□□□□□-□□-□□□□□	ZSE10-□□-□□□□□	0 to -101 kPa/PNP open collector 1 output + analog voltage
ZQ1-ZSFA□□□□□-□□-□□□□□	ZSE10F-□□-□□□□□	100 to -100 kPa/NPN open collector 2 outputs
ZQ1-ZSFB□□□□□-□□-□□□□□	ZSE10F-□□-□□□□□	100 to -100 kPa/PNP open collector 2 outputs
ZQ1-ZSFC□□□□□-□□-□□□□□	ZSE10F-□□-□□□□□	100 to -100 kPa/NPN open collector 1 output + analog voltage
ZQ1-ZSFE□□□□□-□□-□□□□□	ZSE10F-□□-□□□□□	100 to -100 kPa/PNP open collector 1 output + analog voltage








**Dimensions**

Manifold type (without PD port)

ZQ1□□-BSB

\*ZQ1□□3M-□□□□□□-□□□□□□-□□



**Dimensions**

	(mm)							
n	1	2	3	4	5	6	7	8
L1	26	36	46	56	66	76	86	96
L2	42	52	62	72	82	92	102	112

Note 1) The above dimensions are for ZQ104-BSB.

- \* ZQ1□□3M-K1□□<sup>5</sup>/<sub>8</sub>L-E□□G-00.
- \* ZQ1□□3M-K2<sup>5</sup>/<sub>8</sub>L-E□□GK-00.
- \* ZQ1□□3M-J1□□<sup>5</sup>/<sub>8</sub>L-F-00.
- \* ZQ1□□3M-Q1<sup>5</sup>/<sub>8</sub>L-E□□-00.
- \* In case of ZQ1□□3M-K□□□□□□-F□□-00, the overall length is 87.2.
- \* In case of ZQ1□□3M-N□□□□□□-F□□-00, the overall length is 90.7.
- \* In case of ZQ1□□3M-K□□□□□□-F□□□□□□-00, the overall length is 107.5.
- \* In case of ZQ1□□3M-N□□□□□□-F□□□□□□-00, the overall length is 111.


Note 2) \* The above dimensions are for ZQ1□□3M-K<sup>5</sup>/<sub>8</sub>□□□□□□-F□□□□□□-□□.

Note 3) \* Dimensions marked with "\*" are those after the attached square bracket is mounted.

Note 4) When the body is mounted, tighten with a torque of 0.6 ± 0.06 N·m. Using excessive torque may cause damage to the body.

Note 5) The pitches of V ports are determined assuming the use of the KJ series one-touch fittings. If used with other fittings, these may cause interference, dependant on their type and size. Please refer to the catalog to confirm the sizes of the fittings to be used.

Note 6) When the release valve is not used, design the circuit for vacuum release separately in order to release a workpiece.






**Dimensions**

**Fittings / Fitting type filter dimensions after installation**


**V port**

<With vacuum pressure switch>




**V port**

<Suction filter only>



**P port (for ejector)**



# Made to Order Specifications



Please contact SMC for detailed dimensions, specifications, and lead times.

## 1 Port Exhaust Specifications

Manifold ZZQ1 Stations\* - B2B - X125

• Port exhaust specifications


Exhaust port is changed for "Port Exhaust Specifications."

## Dimensions


Manifold type (without PD port)

ZZQ1□-B2B-X125

\*ZQ1□3M-□□□□□□-□□□□□□-□□(-Q)



### Manifold Exploded View



### Component Parts

No.	Description	Part no.
1	Hexagon socket head cap screw	Refer to "How to Order" below.
2	End block L	Refer to "Table (1)" (including 1 pc. of ⑥).
3	End block R	Refer to "Table (1)" (including 1 pc. of ⑤).
4	Ejector assembly	ZQ1□□3M-□□□□□□-□□□□□□□□ (-Q) <sup>Note 1)</sup> (1 pc. each in ⑤ and ⑥ is included.)
5	Ejector body gasket for manifold	ZQ-3-005-10AS <sup>Note 2)</sup>
6	Exhaust block gasket	ZQ-3-009-10AS <sup>Note 2)</sup>

Note 1) Refer to pages 1 and 2 for detailed description of "How to Order".  
 Note 2) 10 pcs. are included in one set.

**Table (1)**

Description	With PD port	Without PD port
End block L	ZQ1L-2-BSB-AS	ZQ1L-1-BSB-AS
End block R	ZQ1R-2-BSB-AS	ZQ1R-1-BSB-AS

### Working Procedure

#### Disassembly


Loosen and remove the clamp rod ①.

#### Assembly

1. Install the ejector body gasket for manifold ⑤ into the gasket groove of each ejector assembly ④. Install the exhaust block gasket ⑥ around the projected part.
2. Install the exhaust block gasket ⑥ around the projected part of the end block L ②.
3. Install the ejector body gasket for manifold ⑤ into the gasket groove of the end block R ③.
4. Align the ejector assemblies ④, end block (L) ②, and end block (R) ③ using positioning pins (at the two "a" positions) and fasten with clamp rods ① (2 pcs.) (with a tightening torque of 0.6 N·m ± 0.06 N·m).

### Replacement of V Port Fittings (With vacuum pressure switch)

V port fittings are cassette style for easy replacement. The fittings are blocked by a clip. Remove the clip with a flat blade screwdriver, etc. to replace the fittings. When mounting the fittings, after inserting the fitting assembly until it stops, then put the clip into the prescribed position completely.



### How to Order Hexagon Socket Head Cap Screw

## ZQ-STB 05

#### Number of stations

01	1 station
02	2 stations
⋮	⋮
08	8 stations

Note) 2 pcs. are included in one set.


Applicable tubing O.D.	Straight	Elbow
Applicable tubing O.D. ø3.2	VVQ1000-50A-C3	VVQ1000-F1-LC3
Applicable tubing O.D. ø4	VVQ1000-50A-C4	VVQ1000-F1-LC4
Applicable tubing O.D. ø6	VVQ1000-50A-C6	—
M5 female thread	VVQ1000-50A-M5	—

# Space Saving Vacuum Pump System




[Option]  
Note) CE-compliant:  
For DC only.

# Series ZQ



## How to Order

### Vacuum Pump Unit



#### ① Body type

<b>U</b>	For single unit
<b>M</b>	For manifold

#### ② Solenoid valve combination (Refer to Table (1).)

Symbol	Supply valve	Vacuum release valve
<b>K1</b>	Normally closed	Normally closed
<b>K2</b> Note 1)	Normally open	Normally closed
<b>J1</b>	Normally closed	None
<b>J2</b> Note 1)	Normally open	None
<b>Q1</b>	Latching positive common	Normally closed
<b>Q2</b>	Latching positive common	None
<b>N1</b>	Latching negative common	Normally closed
<b>N2</b>	Latching negative common	None

⚠ The air in the adsorption section of this product is not released to the atmosphere at the vacuum suspension state.  
As for K1, K2, Q1 and N1, use the vacuum release valve when a workpiece is detached.  
Concerning J1, J2, Q2 and N2, devise the circuit for the vacuum release additionally when a workpiece is detached.

Note 1) In cases when K2 or J2 (supply valve normally open) is selected for the solenoid valve combination, when vacuum is stopped for long periods of time (10 minutes or more), do not continue to energize the supply valve, and shut off the air supply.

#### ③ Pilot valve (Refer to Table (1).)

<b>Nil</b>	Standard (DC: 1 W) Note 2)
<b>Y</b>	DC low wattage type (0.5 W) Note 2)

Note 2) Avoid energizing the solenoid valve for long periods of time. (Refer to Specific Product Precautions 1; Caution on Design and Selection.)

#### ④ Solenoid valve rated voltage (Refer to Table (1).)

		CE compliant
<b>1</b> Note 3)	100 VAC (50/60 Hz)	—
<b>2</b> Note 3)	200 VAC (50/60 Hz)	—
<b>3</b> Note 3)	110 VAC (50/60 Hz)	—
<b>4</b> Note 3)	220 VAC (50/60 Hz)	—
<b>5</b>	24 VDC	●
<b>6</b>	12 VDC	●




Note 3) CE compliant products are not available for "1", "2", "3" and "4".

**Table (1) Combination of Solenoid Valve, Pilot Valve and Rated Voltage**

Combination no.	Solenoid valve combination symbol	Pilot valve symbol	Applicable power supply voltage (V)					
			100 AC	200 AC	110 AC	220 AC	24 DC	12 DC
①	<b>K1</b>	<b>Nil</b>	—	—	—	—	●	●
②	<b>K1</b>	<b>Y</b>	—	—	—	—	●	●
③	<b>K2</b>	<b>Nil</b>	—	—	—	—	●	●
④	<b>J1</b>	<b>Nil</b>	●	●	●	●	●	●
⑤	<b>J1</b>	<b>Y</b>	—	—	—	—	●	●
⑥	<b>J2</b>	<b>Nil</b>	—	—	—	—	●	●
⑦	<b>Q1</b>	<b>Nil</b>	—	—	—	—	●	●
⑧	<b>Q2</b>	<b>Nil</b>	●	●	●	●	●	●
⑨	<b>N1</b>	<b>Nil</b>	—	—	—	—	●	●
⑩	<b>N2</b>	<b>Nil</b>	—	—	—	—	●	●

\* Combinations ① to ⑩ in the above table are the only possible options.

## ⑤ Electrical entry

<b>L</b>	L-type plug connector, with 0.3 m lead wire, with light/surge voltage suppressor	
<b>LO</b>	L-type plug connector, without connector, with light/surge voltage suppressor	
<b>G</b>	Grommet, with 0.3 m lead wire (Latching/AC type: Not applicable)	

## ⑥ Manual override Note 4)

<b>Nil</b>	Non-locking push type Latching type: Push-locking type
<b>B</b>	Locking type (Q1/Q2/N1/N2: Not applicable)

Note 4) Latching type supply valve: Available in "Nil" only.  
In this case, the supply valve and release valve come with a push-locking type.

## ⑦ Vacuum pressure switch suction filter Note 5)

<b>EA</b>	0 to -101 kPa/NPN open collector 2 outputs, with suction filter
<b>EB</b>	0 to -101 kPa/PNP open collector 2 outputs, with suction filter
<b>EC</b>	0 to -101 kPa/NPN open collector 1 output + analog voltage, with suction filter
<b>EE</b>	0 to -101 kPa/PNP open collector 1 output + analog voltage, with suction filter
<b>FA</b>	100 to -100 kPa/NPN open collector 2 outputs, with suction filter
<b>FB</b>	100 to -100 kPa/PNP open collector 2 outputs, with suction filter
<b>FC</b>	100 to -100 kPa/NPN open collector 1 output + analog voltage, with suction filter
<b>FE</b>	100 to -100 kPa/PNP open collector 1 output + analog voltage, with suction filter
<b>F</b>	Suction filter only

Note 5) The filter included in this product is of a simple type, and will become clogged quickly in environments with high quantities of dust or particulates. Please make additional use of an air suction filter of the ZFA, ZFB or ZFC series.

### **⚠ Warning**

The filter case of this suction filter is made of nylon. Contact with alcohol or similar chemicals may cause it to be damaged. Also, do not use the filter when these chemicals are present in the atmosphere.

## ⑩ Fitting (P port) Note 8)

Symbol	Applicable tubing O.D.	Part no.	
		Vacuum pressure switch	Filter only
<b>0</b>	Without fitting (M5 x 0.8)	VVQ1000-50A-M5	—
<b>1</b>	ø3.2 (Straight)	VVQ1000-50A-C3	KJS23-M5
<b>2</b>	ø4 (Straight)	VVQ1000-50A-C4	KJS04-M5
<b>3</b>	ø6 (Straight)	VVQ1000-50A-C6	KJS06-M5
<b>4</b>	ø3.2 (Elbow)	VVQ1000-F1-LC3	KJL23-M5
<b>5</b>	ø4 (Elbow)	VVQ1000-F1-LC4	KJL04-M5

## ⑫ Bracket A

<b>Nil</b>	With bracket A
<b>N</b>	Without bracket A

## ⑬ CE-compliant

<b>Nil</b>	—
<b>Q</b>	CE-compliant

Note) CE-compliant: For DC only.

## ⑧ Vacuum pressure switch unit specifications

<b>Nil</b>	With unit switching function <small>Note 6)</small>
<b>M</b>	Fixed SI unit <small>Note 7)</small>
<b>P</b>	With unit switching function <small>Note 6)</small> (Initial value psi)

Note 6) Under the New Measurement Law, sales of switches with the unit switching function are not allowed for use in Japan.

Note 7) Fixed unit: kPa

## ⑨ Vacuum pressure switch lead wire specifications

<b>Nil</b>	Without connector
<b>G</b>	Lead wire with connector (Lead wire length 2 m) With connector cover

## ⑪ Fitting (PS / PV port) Note 8)

Symbol	Applicable tubing O.D.	Part no.	Object spec.
<b>Nil</b>	Without port	—	Manifold
<b>0</b>	Without fitting (M5 x 0.8)	—	Single unit
<b>2</b>	ø4 (Straight)	KJS04-M5	
<b>3</b>	ø6 (Straight)	KJS06-M5	
<b>5</b>	ø4 (Elbow)	KJL04-M5	

Note 8) For filter only (Without vacuum pressure switch)

When neither V port fitting nor PS/PV port fitting are needed, enter nothing or -00 in the dotted line above "How to Order".

## How to Order

**Manifold**

**ZZQ1 08 - 0**

Number of stations ●

01	1 station
02	2 stations
⋮	⋮
08	8 stations

Vacuum pressure supply port (PV port)  
Port location  
(Refer to Table (1).)


L	Left side
R	Right side



## Manifold Ordering Example

ZZQ108-R0B → 1 pc.  
\*ZQ1000M-K15L-EAG (-Q)  
→ 4 pcs. (Stations 1 to 4)  
\*ZQ1000M-K1Y5L-EAG (-Q)  
→ 4 pcs. (Stations 5 to 8)

Note) By viewing the front side of vacuum port (V), stations are counted starting from station 1 on the left side.



Vacuum port / 1 2 3 4 5 6 7 8  
ZQ1053M-K1Y5L-EAG ZQ1103M-K1Y5L-EAG

**Table (1) Air Pressure Supply Port Location on the Manifold**

PD port	Manifold		Left			Right		
	Port location		PS	PV	PD	PS	PV	PD
B	L (Left side)		—	●	—	● (Note)	—	—
	R (Right side)		● (Note)	—	—	—	●	—
C	L (Left side)		—	●	●	●	—	●
	R (Right side)		●	—	●	—	●	●

Note) The position of each port is shown as right and left sides viewed from the front side of the vacuum port.

Release pressure is commonly supplied from the PS port.

\* PS: Pilot pressure supply port, PV: Vacuum pressure supply port, PD: Release pressure supply port

Release pressure supply port (PD port) ●

B	None (Release pressure is supplied from the PS port.)
C	Provided (Air can be alternatively supplied from the PS port.)

## Specifications

### Common

Switching method for vacuum/release valve	Piloted	
Cv factor	0.11	
Supply pressure range	Vacuum pressure supply port (PV)	0 to -101.3 kPa
	Pilot/Pressure port (PS)	0.3 to 0.5 MPa (Normally open: 0.3 to 0.45 MPa)
	Supply pressure port for vacuum release (PD)	0.3 to 0.5 MPa (Normally open: 0.3 to 0.45 MPa), and also PD pressure ≤ PS pressure
Operating temperature range	5 to 50°C	
Fluid	Air / Inert gas	

### Weight

Single unit	With suction filter <sup>Note 1)</sup>	95 g
	With vacuum pressure switch and suction filter <sup>Note 2)</sup>	109 g
End plate assembly for manifold		122 g

Note 1) Including a 0.3 m connector for supply valve and vacuum release valve.

Note 2) Including a 0.3 m connector for supply valve and vacuum release valve and a 2 m connector for vacuum pressure switch.

◎ Calculation of weight for the manifold type  
(Single unit weight) x (Number of stations) +  
(Weight of end plate assembly for manifold)

Example) Vacuum pressure switch + 8 stations with suction filter  
109 g x 8 + 122 g = 994 g

### Supply Valve / Vacuum Release Valve

Item	Type	Normally closed		Latching type	Normally open
		Standard (1 W)	Low wattage type (0.5 W)		
Model (Refer to "How to Order" for solenoid valves on page 19.)		VQ110-□	VQ110Y-□	VQ110 <sup>L</sup> <sub>N</sub> -□	ZQ1-VQ120-□
Manual override		Non-locking push type / Locking type (Tool type)		Push-locking type	Non-locking push type / Locking type (Tool type)
Rated coil voltage		12, 24 VDC, 100, 110, 200, 220 VAC	12, 24 VDC	12, 24 VDC, 100, 110, 200, 220 VAC	12, 24 VDC
Power consumption (current value)	DC	1 W	0.5 W	1 W	
	100 VAC	0.5 VA (5 mA)	—	0.6 VA (6 mA)	—
	110 VAC	0.55 VA (5 mA)	—	0.65 VA (5.9 mA)	—
	200 VAC	1.0 VA (5 mA)	—	1.2 VA (6 mA)	—
Electrical entry		Grommet L plug connector L-type plug connector (with light/surge voltage suppressor)		L plug connector (with light/surge voltage suppressor)	Grommet Light/ Surge voltage suppressor (with light/surge voltage suppressor)

## Specifications


### Vacuum Pressure Switch

Model	ZQ1-ZSE (ZSE10)	ZQ1-ZSF (ZSE10F)
<b>Rated pressure range</b>	0 to -101 kPa	-100 to 100 kPa
<b>Set pressure range/Display pressure range</b>	10 to -105 kPa	-105 to 105 kPa
<b>Withstand pressure</b>	500 kPa	
<b>Minimum setting unit</b>	0.1 kPa	
<b>Power supply voltage</b>	12 to 24 VDC ±10%, Ripple (p-p) 10% or less (with power supply polarity protection)	
<b>Current consumption</b>	40 mA or less	
<b>Switch output</b>	NPN or PNP open collector: 2 outputs (selectable)	
<b>Maximum load current</b>	80 mA	
<b>Maximum applied voltage</b>	28 V (with NPN output)	
<b>Residual voltage</b>	2 V or less (with load current of 80 mA)	
<b>Response time</b>	2.5 ms or less (Response time selections with anti-chattering function: 20, 100, 500, 1000 and 2000 ms)	
<b>Short circuit protection</b>	With short-circuit protection	
<b>Repeatability</b>	±0.2% F.S. ±1 digit	
<b>Hysteresis</b>	Variable (0 or above) <sup>Note 1)</sup>	
<b>Hysteresis mode</b>		
<b>Window comparator mode</b>		
<b>Analog output</b>	<b>Voltage output</b>	Output voltage (rated pressure range) 1 to 5 V ±2.5% F.S.
	<b>Linearity</b>	±1% F.S. or less
	<b>Output impedance</b>	Approx. 1 kΩ
<b>Display system</b>	3 1/2-digit, 7 segment LED 1-color display (Red)	
<b>Display accuracy</b>	±2% F.S. ±1 digit (at ambient temperature of 25 ±3°C)	
<b>Operation indicator light</b>	Lights when ON, OUT1: Green, OUT2: Red	
<b>Environmental resistance</b>	<b>Enclosure</b>	IP40
	<b>Ambient humidity range</b>	Operating/Stored: 35 to 85% RH (with no condensation)
	<b>Withstand voltage</b>	1000 VAC for 1 min. between live parts and case
	<b>Insulation resistance</b>	50 MΩ or more (at 500 VDC) between live parts and case
	<b>Vibration resistance</b>	10 to 150 Hz at the smaller of amplitude 1.5 mm or acceleration 20 m/s <sup>2</sup> in X, Y, Z directions for 2 hrs. each (De-energized)
<b>Impact resistance</b>	100 m/s <sup>2</sup> in X, Y, Z directions 3 times each (De-energized)	
<b>Temperature characteristics</b>	±2% F.S. (at 25°C of ambient temperature range between -5 and 50°C)	
<b>Lead wires</b>	Oil-resistant cabtire cord Cross section: 0.15 mm <sup>2</sup> (AWG26), 5 cores, Conductor O.D.: 1.0 mm	

Note 1) If the applied voltage fluctuates around the set-value, the hysteresis must be set to a value more than the fluctuating width, otherwise chattering will occur.

Note 2) For others, refer to ejector specifications on page 17.

## Construction



### Component Parts

No.	Description	Material
1	Poppet valve assembly for supply valve	—
2	Poppet valve assembly for vacuum release valve	—
3	Vacuum release flow adjusting needle	Aluminum alloy

### Replacement Parts

No.	Description	Material	Part no.
4	Solenoid valve	—	Refer to page 19.
5	Filter element	PVF	XT534-5-001-AS
6	Vacuum pressure switch	—	Refer to page 19.
7	Fitting	—	Refer to "How to Order" on page 19.







# Series ZQ

## Dimensions

### Type K2



ZQ1000U-K2□□□□-□□□□-□□□□



- Note 1) The above dimensions are for ZQ1000U-J1□□□□-F-00. In case of ZQ1000U-K1□□□□-F□□□□-00, the overall length is 113.3.
- Note 2) The dimensions after bracket A is mounted are the same as those of the K1 type.
- Note 3) When the body is mounted, tighten with a torque of  $0.6 \pm 0.06 \text{ N}\cdot\text{m}$ . Using excessive torque may cause damage to the body.
- Note 4) The pitches of PS, PE, PV and V ports are determined assuming the use of the KJ series one-touch fittings. If used with other fittings, these may cause interference, dependant on their type and size. Please refer to the catalog to confirm the sizes of the fittings to be used.

### Type J2

ZQ1000U-J2□□□□-□□□□-□□□□




- Note 1) The above dimensions are for ZQ1000U-J1□□□□-F-00. In case of ZQ1000U-K1□□□□-F□□□□-00, the overall length is 113.3.
- Note 2) The dimensions after bracket A is mounted are the same as those of the K1 type.
- Note 3) When the body is mounted, tighten with a torque of  $0.6 \pm 0.06 \text{ N}\cdot\text{m}$ . Using excessive torque may cause damage to the body.
- Note 4) The pitches of PS, PE, PV and V ports are determined assuming the use of the KJ series one-touch fittings. If used with other fittings, these may cause interference, dependant on their type and size. Please refer to the catalog to confirm the sizes of the fittings to be used.
- Note 5) In order to release a workpiece, design the circuit for vacuum release separately.


## Dimensions

### Type Q1, N1

ZQ1000U-Q1  $\square^5 \square \square - \square \square \square \square - \square \square$   
 ZQ1000U-N1  $\square^5 \square \square - \square \square \square \square - \square \square$



### Circuit diagram



Note 1) The above dimensions are for ZQ1000U-Q1  $\square^5 \square \square - \square \square \square \square - \square \square$ .  
 In case of ZQ1000U-Q1  $\square^5 \square \square - \square \square \square \square - \square \square$ , the overall length is 87.2.


Note 2) The dimensions after bracket A is mounted are the same as those of the K1 type.

Note 3) When the body is mounted, tighten with a torque of  $0.6 \pm 0.06 \text{ N}\cdot\text{m}$ .  
 Using excessive torque may cause damage to the body.


Note 4) The pitches of PS, PV, V and PE ports are determined assuming the use of the KJ series one-touch fittings. If used with other fittings, these may cause interference, dependant on their type and size. Please refer to the catalog to confirm the sizes of the fittings to be used.

### Type Q2, N2

ZQ1000U-Q2  $\square \square - \square \square \square \square - \square \square$   
 ZQ1000U-N2  $\square^5 \square \square - \square \square \square \square - \square \square$



### Circuit diagram



Note 1) The above dimensions are for ZQ1000U-Q2  $\square \square - \square \square \square \square - \square \square$ .  
 In case of ZQ1000U-Q2  $\square \square - \square \square \square \square - \square \square$ , the overall length is 87.2.

Note 2) The dimensions after bracket A is mounted are the same as those of the K1 type.

Note 3) When the body is mounted, tighten with a torque of  $0.6 \pm 0.06 \text{ N}\cdot\text{m}$ .  
 Using excessive torque may cause damage to the body.

Note 4) The pitches of PS, PV, V and PE ports are determined assuming the use of the KJ series one-touch fittings. If used with other fittings, these may cause interference, dependant on their type and size. Please refer to the catalog to confirm the sizes of the fittings to be used.

Note 5) In order to release a workpiece, design the circuit for vacuum release separately.




## Dimensions

Manifold type (with PD port)

ZZQ1□□-□OC

\*ZQ1000M-□□□□□-□□□□□-□□□



## Dimensions

n	1	2	3	4	5	6	7	8
<b>L1</b>	26	36	46	56	66	76	86	96
<b>L2</b>	42	52	62	72	82	92	102	112

Note 1) The above dimensions are for ZZQ104-LOC.

\* ZQ1000M-K1□□<sup>5</sup>/<sub>6</sub>L-E□G-00.

\* ZQ1000M-K2□□<sup>5</sup>/<sub>6</sub>L-E□G-00.

\* ZQ1000M-J1□□<sup>5</sup>/<sub>6</sub>L-F-00.

\* ZQ1000M-Q1□□<sup>5</sup>/<sub>6</sub>L-E□G-00.

\* In case of ZQ1000M-□□□□□-F-00, the overall length is 91.7.

\* In case of ZQ1000M-□□□□□-E□G-00, the overall length is 112.


Note 2) \* The above dimensions are for ZQ1000M-K<sup>5</sup>/<sub>6</sub>□□□□□□□□□□.

Note 3) When the body is mounted, tighten with a torque of  $0.6 \pm 0.06$  N·m.

Using excessive torque may cause damage to the body.

Note 4) The pitches of V ports are determined assuming the use of the KJ series one-touch fittings. If used with other fittings, these may cause interference, dependant on their type and size. Please refer to the catalog to confirm the sizes of the fittings to be used.

Note 5) When the vacuum release valve is not used, design the circuit for vacuum release separately in order to release a workpiece.




# Series ZQ

## Dimensions

### Fittings / Fitting type filter dimensions after installation


#### V port

<With vacuum pressure switch>




#### V port

<Suction filter only>



#### PS / PV port (for pump)







# Series ZQ

## Specific Product Precautions

Be sure to read before handling.

Refer to "Handling Precautions for SMC Products" (M-E03-3) for Vacuum Equipment Precautions.

### Design and Selection

#### Warning

##### 1. Avoid energizing the solenoid valve for long periods of time.

If a solenoid valve is energized for a long period of time, the coil will get hot and the performance may be reduced. Additionally, the peripheral equipment in close proximity may also be badly affected. Use a low wattage solenoid valve when the solenoid valve is energized continuously or when the duration of the energization is longer than the non-energized period each day. Periods of energization can be shortened by using a normally opened or latching type solenoid valve. But, do not energize the coil on both A and B sides simultaneously when using the latching type.

Continuous energization of the solenoid valve should be less than 10 minutes in duration and the energization period should be shorter than the non-energized period. Take measures for any heat radiation so that the temperature is within the range of solenoid valve specifications when the solenoid valve is mounted on the control panel. Please pay special attention to any temperature increases when a manifold type with 3 stations or more is energized continuously or when three individual units are placed in close proximity.

##### 2. Use the vacuum equipment within the operating supply pressure range.

When the operating with a lower supply pressure, the vacuum performance will be reduced and the poppet valve will cause malfunction.

Never use the vacuum equipment more than the operating supply pressure range as this may cause damage to the product resulting in potentially dangerous operation.

##### 3. Suspension of operation for long periods of time

Please use caution — as detailed below — when the vacuum equipment is turned off for periods in excess of 6 hours.

- Be sure to turn off the pressure supply to the vacuum equipment.

Please observe this precautions as the supply pressure will be applied for a extra period of time due to the line pressure increase and may result in damage to the vacuum equipment.

- Be sure to turn off the power supply to the solenoid valve and the pressure switch.

Please observe this precautions as any heat generated due to the length of energization time may seriously affect the vacuum equipment and peripheral equipment resulting in potentially dangerous operation.

##### 4. Check valve

The check valve has a function to prevent the exhaust air from the silencer overflowing to the vacuum port side when a manifold is used. However, depending on usage conditions, it does not always suppress air overflow to the desired extent. During usage, please inspect thoroughly with actual machine. Also, no guarantee is therefore provided when used for any other purposes. It is especially dangerous if used for the purpose of workpiece drop prevention in the case of operator blackout. Therefore, please take additional measures for providing drop prevention, such as providing a guide.

##### 5. Exhaust port (EXH port) on the vacuum ejector

Please check the exhaust port (EXH port) on the vacuum ejector, so that any exhaust resistance will not be increased due to insulating materials or restrictions in the piping. The exhaust resistance may reduce the ejector's performance. Additionally, never use this product in an application where the exhaust port is blocked when detaching a workpiece. This misuse may result in possible damage to the product.

#### Warning

##### 6. Vacuum release flow adjustment needle

Adjust the vacuum release flow adjustment needle from the fully closed to the open state by 1/8 to 1/4 turns to detach a workpiece completely during the ON time of a release valve. Do not supply compressed air while the vacuum release flow adjustment needle is adjusted. Securely lock it with a lock nut after adjustment.

##### 7. How to use the latching type solenoid valve


Our Latching type solenoid are fitted with a self-detaining mechanism. Its construction features an armature inside the solenoid which is set or reset using spontaneous energization. (20 ms or greater) Therefore, continuous energization is not required.

### How to Use the Latching Type Plug Connector


#### Wiring specifications

- Wiring should be connected as shown below. Connect with the power supply respectively.


#### DC positive common



#### DC negative common



#### AC type



Special care must be taken for the latching type.

1. Avoid using this product with a circuit which electrifies both the set and reset signals simultaneously.
2. The minimum energization time required for self-detaining is 20 ms.
3. Please contact us when using this product in locations where there are vibration levels of 30 m/s<sup>2</sup> or above or highly magnetic fields. No problems arise in normal usage or locations.
4. This valve retains the reset position (Flow path: A → R) at the time of shipment. However, it may alter to the set position during transportation or due to vibration when mounting the valve. Therefore, confirm the home position either manually or with power supply prior to use.

### Mounting

#### Warning

##### 1. Screw tightening torque for mounting the body should be performed with 0.6 ± 0.06 N·m.

Excessive torque may damage the product.