2-Color Display Digital Flow Switch

New

(RoHS)

Applicable fluid Air, N2


Expanded flow range! Wide range of flow measurement with one product

Flow ratio

Setting resolution: 1 L/min Current PF2A: 5 L/min (200 L: 2 L/min)

* Flow ratio is 10: 1 for current PF2A.

Applicable flow range [L/min] 100 150 200 300 2000



Comparison with PFMB7201 and PF2A721-03

Comparison with PFMB7501-04 and PF2A751-04





2-Color Display Digital Flow Switch



Piping variations

Straight

One-touch fitting Ø8



Reversed display mode

When the switch is used upside down, the orientation of the display can be rotated to make it easier to read.

No display rotating function Display is upside down.



Bottom

One-touch fitting Ø8





With display rotating function



Functions (▶Refer to page 15 and 16 for details.)

- Output operation
- Display color
- Reference condition
- Response time
- Display mode
- External input function
- Accumulated value hold
- Analog output hold
- Forced output function
- Analog output free range function
- Power-saving mode
- Peak/Bottom value display
- Keylock function
- Error display function
- Orientation correction function
- · Reversed display mode Reset to the default settings.
- Setting of security code

Bypass structure Sensor unit Protruding Bypass structure with protruding part at the main piping, reduces the contact of moist air with the sensor, reducing degradation of the sensor and maintaining accuracy. Moist air






Digital flow switch to save energy!


Flow control is necessary for promoting energy saving in any application.

Saving energy starts from numerical control of the flow consumption of equipment and lines and clarification of the purpose and effect.




- Digital display allows visualization of flow rate. Remote control is possible with accumulated pulse.
- 2-color display Improved visibility







Applications


Control of purge air flow of ionizer




• Flow control of № gas to prevent lead frame oxidation • Accumulated indication shows the operating flow rate or residual amount (of N2 etc.) in a gas cylinder.








Mounting




Example of Recommended Pneumatic Circuit


Air quality in the product specification can be satisfied by using this pneumatic circuit.



Flow Switch Flow Rate Variations



Flow Switch Variations/Basic Performance Table



[2-Color Display]

Digital Flow Switch



Series PFMB7

How to Order



7 Integrated display

Rated flow range (Flow rate range) **201** 2 to 200 L/min


Flow adjustment valve

Nil	None
S	Yes

Port size

C8	ø8 (5/16") One-touch fitting		
02*	Rc1/4		
N02*	* NPT1/4		
F02*	G1/4 Note 4)		

Note 4) ISO1179-1 compliant *Made to Order



*Made to Order

Output specifications

OUT1		OUT2	
A NPN		NPN	
B PNP		PNP	
C	NPN	Analog 1 to 5 V	
D	NPN	Analog 4 to 20 mA	
E*	PNP	Analog 1 to 5 V	
F*	PNP	Analog 4 to 20 mA	
Ğ	NPN	External input Note)	
H*	PNP External input Note)		

Note) Accumulated flow, peak flow and minimum flow can be reset by external signal input.

*Made to Order

Calibration certificate Note 1)

Nil	None
A *	With calibration certificate

Note 1) Certificate in both English and Japanese *Made to Order

Unit specifications


- Cint opecinications		
M	SI unit only Note 2)	
Nil	Unit selection function Note 3)	

Note 2) Fixed unit: Instantaneous flow: L/min Accumulated flow: L


Note 3) Since the unit for Japan is fixed to SI due to new measurement law, this option is for overseas.

Unit can be changed. Instantaneous flow: L/min⇔cfm Accumulated flow: L⇔ft3

Option 2




Note) Each option is not assembled with the product, but shipped together. If an accessory is required, order separately using "ZS" part numbers.



DIN Rail Mounting Bracket (Order Separately)



2 stations 3 stations 3 4 stations 5 5 stations



- DIN rail is prepared by customer.
- DIN rail is not suitable for port size F02 (G1/4).

2-Color Display Digital Flow Switch Series PFMB7

How to Order

04 - A



Type ● 7 Integrated display

PFMB7501-

Rated flow range (Flow rate range)

<u> </u>	<u> </u>
501	5 to 500 L/min
102	10 to 1000 L/min

Thread type		
Nil	Rc	
N	NPT	
F	G Note)	

Note) ISO228 compliant

Output specifications

OUT1	OUT2			
NPN	NPN			
PNP	PNP			
NPN	Analog 1 to 5 V			
NPN	Analog 4 to 20 mA			
PNP	Analog 1 to 5 V			
PNP	Analog 4 to 20 mA			
NPN	External input Note 4)			
H* PNP External input Note				
	NPN PNP NPN PNP PNP PNP NPN			


Note 4) Accumulated flow, peak flow and minimum flow can be reset by external signal input.

• Calibration certificate Note 1)

Nil	None
\mathbf{A}^*	With calibration certificate

Note 1) Certificate in both English and Japanese *Made to Order

Option 2



Note) Each option is not assembled with the product, but shipped together. If an accessory is required, order separately using "ZS" part numbers.

Unit specifications

М	SI unit only Note 2)
Nil	Unit selection function Note 3)

Note 2) Fixed unit: Instantaneous flow: L/min Accumulated flow: L

Note 3) Since the unit for Japan is fixed to SI due to new measurement law, this option is for overseas.

Unit can be changed. Instantaneous flow: L/min⇔cfm

Accumulated flow: L⇔ft³

Option 1

Option	
Nil	W
With lead wire with connector (2 m)	With lead wire with connector (2 m) + Connector cover (Silicone rubber)
ZS-33-D	ZS-33-F ZS-33-D
N	Note) If an accessory is required, order
No lead wire	separately using "ZS" part numbers.

Option 2/Part No.

Option	Part no.	Qty.	Note
Bracket	7S-42-C	1	PEMB 7501/7102 with self-tanning screw (3 x 6), 4 ncs



^{*}Made to Order

Specifications

Refer to "Handling Precautions for SMC Products" for Flow Switch Precautions and the Operation Manual in our website for Specific Product Precautions.

	Model		PFMB7201	PFMB7501	PFMB7102	
Fluid	Applicable fluid Note 1)		Air, № (Air quality grade is JIS B 8392-1 1.1.2 to 1.6.2, ISO8573-1 1.1.2 to 1.6.2.)			
riuia	Fluid temperat	ure range	0 to 50°C			
	Detection meth			Thermal type		
	Rated flow ran		2 to 200 L/min	5 to 500 L/min	10 to 1000 L/min	
	Set flow rate	Instantaneous flow	2 to 210 L/min	5 to 525 L/min	10 to 1050 L/min	
Flow	range	Accumulated flow	0 to 999,999,999 L	0 to 999,999,990 L		
	Minimum setting unit Instantaneous flow Accumulated flow			1 L/min		
	Accumulated valums nor nules (E		1 L	10 L		
	Accumulated volume per pulse (Pulse width = 50 msec.) Accumulated value hold function Note 2)			Interval of 2 or 5 minutes can be selected.	10 L/pulse	
	Rated pressure		0 to 0.75 MPa	0 to 0.8	MPa	
	Proof pressure		1.0 MPa	1.2 M		
Pressure	Pressure loss			Refer to "Pressure Loss" graph.		
			±5%F.S. (0 to 0.75 MPa, 0.35 MPa reference)	±5%F.S. (0 to 0.8 MPa, 0.6 MPa reference)		
	Power supply	voltage		12 to 24 VDC ±10%	,	
Electrical	Current consu	mption		55 mA or less		
	Protection			Polarity protection		
	Display accura			±3%F.S.		
Note 11) Accuracy	Analog output	accuracy		±3%F.S.		
7.000.00	Repeatability		±1%F.S. (=	±2%F.S. when response time is set to 0.05 s	econds.)	
	Temperature cha	racteristics		±5%F.S. (0 to 50°C, 25°C reference)		
	Output type Output mode			NPN open collector PNP open collector w comparator, Accumulated output or Accur	nulated nulse output modes	
	Switch operation	on	Select from Hysteresis, William	Select from Normal or Reversed output.	nuiateu puise output modes.	
	Maximum load			80 mA		
Switch	Maximum applied volt			28 VDC		
output	Internal voltage drop (R		NPN output type: 1 V or less (at load current 80 mA) PNP output type: 2 V or less (at load current 80 mA)			
	Response time	Note 4)	Select from 0.05 sec., 0.1 sec., 0.5 sec., or 2 sec.			
	Hysteresis Note	5)	Variable from 0			
	Protection		Short circuit protection			
	Output type		Voltage output: 1 to 5 V, Current output: 4 to 20 mA			
Analog	Impedance Voltage output			Output impedance: Approx. 1 kΩ		
output Note 6)	Response time Note 7)			ower supply voltage 24 V: 600 Ω , at power su		
Futamal				ed with the response time of the switch outp		
External input Note 8)				0.4 V or less (reed or solid state) for 30 mse Accumulated flow external reset or Peak/Bo		
iliput ······	Reference condition Note 9)			ct from Standard condition or Normal conditi		
	Display mode		0.00	ct from Instantaneous flow or Accumulated fl		
	Unit Note 10)	Instantaneous flow		L/min or cfm can be selected.		
	Unit Note 10)	Accumulated flow	L or ft ³ can be selected.	L or ft ³ can be	e selected.	
	Dieplayable	Instantaneous flow	-10 to 210 L/min	-25 to 525 L/min	-50 to 1050 L/min	
Display	Displayable range		(Displays [0] when the value is within the -1 to 1 L/min range.)	(Displays [0] when the value is within the -4 to 4 L/min range.)	Displays [0] when the value is within the -9 to 9 L/min range.)	
		Accumulated flow		0 to 999,999,999 L		
	Minimum display	Instantaneous flow		1 L/min		
	unit	Accumulated flow	1 L	101		
	Display Indicator LED		Display method: LED Display color: Red/Green Display: 3 digit 7 segment LED ON when switch output is ON. (OUT1: Green, OUT2: Red)	Display method: LCD Display color: Re LED ON when switch output is		
	Enclosure		LED ON WHEN SWIIGH OULPUL IS ON: (OOT 1: Gleen, OOT 2: Neu)	IP40	ON. (OOT 1/OOT2. Orange)	
	Withstand volt	age	1000 '	VAC for 1 minute between terminals and hou	ısina	
Environmental	Insulation resi	stance	50 MΩ or more (500 VDC measured via megohimmeter) between terminals and housing			
	Operating temper	rature range	Operation: 0 to 50°C, Storage: –10 to 60°C (No condensation or freezing)			
	Operating humi	idity range	Operation, Storage: 35 to 85%RH (No condensation or freezing)			
Standard			CE, UL (CSA), RoHS	CE, Ro		
Piping	Piping specific		Rc1/4, NPT1/4, G1/4, ø8 One-touch fitting	Rc1/2, NPT	1/2, G1/2	
· Piping entry direction			Straight, Bottom			
Main materials of parts in contact with fluid Note 12)		n contact	FKM, Stainless steel 304, PPS, PBT,	ADC, PPS, Stainle		
with fluid	Body		Brass (Electroless nickel plating), HNBR, Si, Au, GE4F Rc1/4, NPT1/4/Straight: 70 g Bottom: 85 g G1/4/Straight: 115 g Bottom: 130 g	HNBR, Si		
	,		ø8 One-touch fitting/Straight: 50 g Bottom: 65 g	100	9	
	Flow adjustme	nt valve	+45 g	_		
Weight	Lead wire		- 3	+35 g		
	Bracket		+20 g	+25	g	
	Panel mount a		+15 g	_		
	DIN rail mountii	ng bracket	+65 g	_		

- Note 1) Refer to "Example of Recommended Pneumatic Circuit" on Features 2.

 Note 2) When using the accumulated value hold function, use the operating conditions to calculate the product life, and do not exceed it. The maximum access limit of the memory device is 1 million cycles. If the product is operated 24 hours per day, the product life will be as follows:
 - 5 min interval: life is calculated as 5 min \times 1 million = 5 million min = 9.5 years
 - $^{\circ}$ 2 min interval: life is calculated as 2 min x 1 million = 2 million min = 3.8 years If the accumulated flow external reset is repeatedly used, the product life will be shorter than calculated life.
- Note 3) Do not release the OUT side piping port of the product directly to the atmosphere without connecting piping. If the product is used with the piping port released to atmosphere, accuracy may vary.
- Note 4) The time from when the flow is changed by a step input (when the flow rate changes from 0 to the maximum flow instantaneously) until the switch output turns ON (or OFF) when set at 90% of the rated flow rate.
- Note 5) If the flow fluctuates around the set value, the width for setting more than the fluctuating width needs to be set. Otherwise, chattering will occur.
- Note 6) When using a product with an analog output
- Note 7) The time from when the flow is changed as a step input (when the flow rate changes from 0 to the maximum flow instantaneously) until the analog output reaches 90% of the rated flow rate.
- Note 8) When using a product with an external input
- Note 9) The flow rate given in the specification is the value at standard condition.

 To convert the units from standard condition to normal condition, use the following conversion calculation:
 - Flow rate at standard condition x 0.927 = Flow rate at normal condition
- Note 10) Setting is only possible for models with the unit selection function.
- Note 11) Refer to "Straight Piping Length and Accuracy" on page 4 for details. Note 12) Refer to "Construction/Fluid Contact Parts" on page 5 for details.
- **SMC**

Flow Range


Model	Flow range					
iviodei	-100 L/min 0 L/m	nin 200 L/min	500 L/min	1000 L/min	2000 L/min	
PFMB7201	2 L/min 2 L/min –10 L/min	200 L/min 210 L/m 210 L/m	nin			
PFMB7501	5 L/min ■ 5 L/min ■ –25 L/min		500 L/min 525 L/min 525 L/min	1		
PFMB7102	10 L/min 10 L/min –50 L/min	l I		1000 L/min 1050 L/min 1050 L/min		
			Rated flow ran	ge Set flow rate rang	je Displayable rang	

Analog Output

Flow/Analog Output


	Α	В	С
Voltage output	1 V	1.04 V	5 V
Current output	4 mA	4.16 mA	20 mA

Model	Rated flow [L/min]		
iviodei	Min.	Max.	
PFMB7201	2	200	
PFMB7501	5	500	
PFMB7102	10	1000	




Flow Adjustment Valve Flow-rate Characteristics






Pressure Loss


PFMB7201 (for 200 L/min) (Without flow adjustment valve)




PFMB7501 (for 500 L/min)



PFMB7102 (for 1000 L/min)




Straight Piping Length and Accuracy



- The piping on the IN side must have a straight section of piping with a length of 8 cm or more. If a straight section of piping is not installed, the accuracy can vary by approximately ±2%F.S.
- * "Straight section" means a part of the piping without any bends or rapid changes in the cross sectional area
- When the PFMB7201 is connected to tubing, use a tube I.D. 5 mm just before the product.
- When the PFMB7501 or 7102 is connected to tubing, use a tube I.D. 9 mm or more just before the product.

The accuracy can vary by approximately $\pm 2\%$ F.S. when such tubing is not used.


PFMB7201/7501/7102







Construction/Fluid Contact Parts

PFMB7201








Component Parts

Con	omponent Parts						
No.	Description	Material	Note				
1	Sensor body	PPS					
2	Gasket	HNBR					
3	Flow rectifier	Stainless steel 304					
4	Sensor chip	Silicone					
5	Printed circuit board	GE4F					
6	Gasket	HNBR					
7	Flow rectifier	Stainless steel 304					
8	O-ring	FKM	Fluoro coating				
9	O-ring	FKM	Fluoro coating				
10	Fitting for piping	Brass	Electroless nickel plating				
_11	O-ring	FKM	Fluoro coating				
12	Body	PBT					
13	Gasket	HNBR					
14	Bottom piping adapter	PBT					
15	O-ring	HNBR	Fluoro coating				
16	Flow adjustment valve body	PBT					
17	Body	Brass	Electroless nickel plating				
18	Needle	Brass	Electroless nickel plating				
19	O-ring	HNBR	Fluoro coating				
20	O-ring	HNBR	Fluoro coating				

PFMB7501/7102



Component Parts


No.	Description	Material	Note
1	Sensor body	PPS	
2	Gasket	HNBR	
3	Flow rectifier	Stainless steel 304	
4	Sensor chip	Silicone	
5	Printed circuit board	GE4F	
6	Gasket	HNBR	
7	Body	PPS	
8	Mesh	Stainless steel 304	
9	Spacer	PPS	
10	O-ring	HNBR	
11	O-ring	HNBR	
12	Attachment	ADC	Coating




2-Color Display Digital Flow Switch Series PFMB7

Dimensions


PFMB7201-C8







Dimensions


PFMB7201-(N)02





PFMB7201-(N)02L










2-Color Display Digital Flow Switch Series PFMB7

Dimensions


PFMB7201-F02










PFMB7201-F02L













Dimensions

PFMB7201S-C8




PFMB7201S-C8L




Dimensions


PFMB7201S-(N)02



PFMB7201S-(N)02L



Dimensions




Dimensions


PFMB7201

Panel mount/


Without flow adjustment valve/Straight



Panel mount/ Without flow adjustment valve/Bottom




Panel Fitting Dimensions




Panel thickness 1 to 3.2 mm

Note) Piping entry direction: Minimum dimensions for bottom piping. If using straight piping, the piping material and tubing need to be taken into consideration when designing the system. If a bend (R) is used, limit it to R3 or less.


Panel mount/ With flow adjustment valve/Straight



Panel mount/ With flow adjustment valve/Bottom



Panel Fitting Dimensions



Panel thickness 1 to 3.2 mm


Note) Piping entry direction: Minimum dimensions for bottom piping. If using straight piping, the piping material and tubing need to be taken into consideration when designing the system. If a bend (R) is used, limit it to R3 or less.




Dimensions

PFMB7201


With bracket/Without flow adjustment valve



With bracket/With flow adjustment valve




DIN rail mounting





- DIN rail is prepared by customer.
- DIN rail is not suitable for port size F02 (G1/4).


Dimensions

PFMB7501/7102










Lead wire with connector ZS-33-D



Cable Specifications

Conductor	Nominal cross section area	AWG26
Conductor	External diameter	Approx. 0.50 mm
Insulation	External diameter	Approx. 1.00 mm
insulation	Colors	Brown, White, Black, Blue
Sheath	Material	Oil-resistant PVC
Finished ex	ternal diameter	ø3.5

Note) For wiring, refer to the Operation Manual from the SMC website Documents/Download-->Instruction Manuals.



Series PFMB Function Details

■ Output operation

The output operation can be selected from the following:

Output (hysteresis mode and window comparator mode) corresponding to instantaneous flow, or output (accumulated output and pulse output) corresponding to accumulated flow.

Note) At the time of shipment from the factory, it is set to hysteresis mode and normal output.

■ Display color

The display color can be selected for each output condition. The selection of the display color provides visual identification of abnormal values. (The display color depends on OUT1 setting.)

Green for ON, Red for OFF Red for ON, Green for OFF Red all the time Green all the time

■ Reference condition

The display unit can be selected from standard condition or normal condition.

Standard condition: Flow rate converted to a volume at 20°C and 1 atm (atmosphere)

Normal condition: Flow rate converted to a volume at 0°C and 1 atm (atmosphere)

■ Display mode

The display mode can be selected from instantaneous flow or accumulated flow.

Instantaneous flow display

Accumulated flow display

■ Response time

The response time can be selected to suit the application. (default setting is 1 second.)

Abnormalities can be detected more quickly by setting the response time to 0.05 seconds.

The effect of fluctuation and flickering of the display can be reduced by setting the response time to 2 seconds. 0.05 sec. 0.1 sec. 0.5 sec. 1 sec. 2 sec.

■ Power-saving mode

The display can be turned off to reduce the power consumption. In this power-saving mode, decimal points flash on the main screen. If any button is pressed during power-saving mode, the display is reverts to normal for 30 seconds to allow checking of the flow etc.

■ Setting of security code

The user can select whether a security code must be entered to release key lock. At the time of shipment from the factory, it is set such that the security code is not required.

■ External input function

This function can be used only when the optional external input is present. The accumulated flow, peak value and bottom value can be reset remotely.

Accumulated flow external reset: A function to reset the accumulated flow value

when an external input signal is applied. In accumulated increment mode, the accumulated value will reset to, and increase from zero. In accumulated decrement mode, the accumulated value will reset to, and decrease from the set value.

* When the accumulated value is memorized, every time the accumulated flow external reset is activated, the memory device (EEPROM) will be accessed. Take into consideration the maximum number of times the memory device can be accessed, 1 million times. The total of external input times and accumulated value memorizing time interval should not exceed 1 million times.

Peak/Bottom reset: Peak and bottom value are reset.

■ Forced output function

The output is turned on/off in a fixed state when starting the system or during maintenance. This enables confirmation of the wiring and prevents system errors due to unexpected output.

For the analog output type, when ON the output will be 5 V or 20 mA, and when OFF, it will be 1 V or 4 mA.

* Also, the increase or decrease of the flow and temperature will not change the on/off status of the output while the forced output function is activated.

■ Accumulated value hold

Accumulated value is not cleared even when the power supply is turned off.

The accumulated value is memorized every 2 or 5 minutes during measurement, and continues from the last memorized value when the power supply is turned on again.

The life time of the memory element is 1 million access cycles. Take this into consideration before using this function.

■ Peak/Bottom value display


The maximum (minimum) flow rate is detected and updated from when the power supply is turned on. In peak (bottom) value display mode, this maximum (minimum) flow rate is displayed.

■ Keylock function

Prevents operation errors such as accidentally changing setting values.


■ Analog output free range function

Allows the flow that generates an output of 5 V or 20 mA to be changed. The value can be changed 10% of maximum rated flow to maximum display value.



■ Reversed display mode

When the switch is used upside down, the orientation of the display can be rotated to make it easier to read by using the display rotating function.



■ Reset to the default settings.

The product can be returned to its factory default settings.



Function Details Series PFMB

■ Error display function -

When an error or abnormality arises, the location and contents are displayed.

Display		Description	Contents	Action	
Erl		OUT1 over current error	Load current of 80 mA or more is applied to the switch output (OUT1).	Eliminate the cause of the overcurrent by turning off the power supply and then turn	
Er2		OUT2 over current error	Load current of 80 mA or more is applied to the switch output (OUT2).	on it again.	
HHH		Instantaneous flow error	The flow rate exceeds the upper limit of indicated flow rate range.	Decrease the flow rate.	
LLL		Reverse flow error	There is a reverse flow equivalent to -5% or more.	Turn the flow to correct direction.	
(*999" will flash in any of upper, middle, lower 3-digit displays.)		Accumulated flow error	The flow rate exceeds the accumulated flow rate range.	Clear the accumulated flow rate.	
Er O					
Er4			Displayed if an internal error has occurred.	Turn the power off and on again.	
Er8		System error			
Er8					

If the failure cannot be solved after the above instructions are performed, please contact SMC for investigation.





⚠ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.

Caution indicates a hazard with a low level of risk Caution: which, if not avoided, could result in minor or moderate injury.

Warning indicates a hazard with a medium level of ** Warning: risk which, if not avoided, could result in death or serious injury.

⚠ Danger :

Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

*1) ISO 4414: Pneumatic fluid power – General rules relating to systems. ISO 4413: Hydraulic fluid power - General rules relating to systems. IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements)

ISO 10218-1: Manipulating industrial robots - Safety.

⚠ Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications. Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
 - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
 - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following
 - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
 - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
 - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

⚠ Caution

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/ **Compliance Requirements**

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.*2)
 - Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
 - 2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

▲ Safety Instructions | Be sure to read "Handling Precautions for SMC Products" (M-E03-3) before using.

SMC Corporation

Akihabara UDX 15F

4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN

Phone: 03-5207-8249 Fax: 03-5298-5362

http://www.smcworld.com

© 2013 SMC Corporation All Rights Reserved